

---

by



# Blaze PowerZone Connect 2 Zone Series With Dante Crestron Home Driver

## User Guide

## Product Manual

[PowerZone Connect 2 Zone Series With Dante Manual](#)

## Overview

Package name (pkg) : AVSwitch\_Blaze\_PowerZone\_2\_Zone\_Dante\_IP.pkg

Version : 1.2.2

This module allows integration of PowerZone Connect 2 Zone Series With Dante into a Crestron Home system. The PowerZone Connect 2 Zone Series With Dante is an audio switcher with analog and S/PDIF inputs, along with virtual mixer inputs to allow the real inputs to be mixed together into a single channel, with adjustable gain levels.

The AVSwitch module in this package provides the usual audio switching, volume and mute capabilities provided by the *AV Switch* driver type.

The Platform module in this package is an optional extra, which generates 1 Extension driver for each

virtual mixer channel, providing an interface to adjust the mixer input gain levels from within the Crestron Home UI.

## Features

This driver provides the following functionality.

- Switching
- Volume Control
- Mute Control

## Blaze Configuration

Prior to setting the driver up in Crestron Home ensure that the Blaze PowerZone Connect 2 Zone Series With Dante is fully configured and works correctly. Please refer to documentation provided by Blaze to setup the unit (link at top of document).

## Support

If you require support for this driver please fill in a support request at <https://support.janustechology.co.uk/>

Please ensure you provide the following information.

- Driver version you are using.
- Platform you are using e.g. Crestron Home
- Firmware version of your Blaze PowerZone Connect 2 Zone Series With Dante.
- Firmware version of your Crestron system.
- A full description of the issue you are having and how to recreate the issue.

## Troubleshooting

- Confirm that correct IP address is entered into the IP address field
  - Confirm that correct Port is entered (if required).
  - Check the Blaze PowerZone Connect 2 Zone Series With Dante can be pinged from the control system controller. If the ping fails check your network configuration and cabling.
  - For IP devices we recommend using a static IP address. Ensure this is done in either the device or router.
-

# Blaze PowerZone Connect 2 Zone Series With Dante Crestron Driver

## Release Notes

**SimplWindows Module:** PowerZone Connect 2 Zone Series With Dante

**Category:**

**Current version:** 1.2.2

## Changes

Date 27th March 2024 - Version - v1.2.2

- Updated Model Name

Date 8th Jan 2024 - Version - v1.2.1

- Updated Model Name

Date 12th Dec 2023 - Version - v1.2.0

### Version

- Module: Blaze\_PowerZone Connect 2 Zone Series With Dante
- Firmware: 1.5.0
- MC4 FW: 2.8000.00010
- Crestron Home Version - v3.011.0070
- Simpl Windows - 4.2500.04.00
- Device Database - 200.280.002.00
- Crestron Database - 219.05.001.00
- Simpl+ - 4.06
- Simpl+ Cross Compiler - 1.3
- Vision Tools Pro-e - 6.2.02
- Smart Graphics Version - 2.19.00.09

### Enhancements

- Added dante on Some models

- Added Mixers Support

## **Bug Fixes**

## **Exceptions**

- (Crestron Home) Volume Up/Down does not work due to a bug with Crestron Home

## **User Impacted**

- N/A

Date 19th July 2023 - Version - v1.1.1

## **Version**

- Module: Blaze\_PowerZone Connect 2 Zone Series With Dante
- Firmware: 1.4.0
- MC4 FW: 2.8000.00010
- Crestron Home Version - v3.011.0070
- Simpl Windows - 4.2500.04.00
- Device Database - 200.280.002.00
- Crestron Database - 219.05.001.00
- Simpl+ - 4.06
- Simpl+ Cross Compiler - 1.3
- Vision Tools Pro-e - 6.2.02
- Smart Graphics Version - 2.19.00.09

## **Enhancements**

- Added support for new virtual Mix inputs
- Allow input selection for Off
- Added signals to set primary input ducking mode
- (Crestron Home) Added power on/off commands for the device
- (Crestron Home) Created new Platform+Extension drivers for adjusting mix input gain levels

## **Bug Fixes**

- (Crestron Home) Correctly disposed of AV Switcher module when removed

## **Exceptions**

- (Crestron Home) Volume Up/Down does not work due to a bug with Crestron Home

## **User Impacted**

- N/A

Date 27th April 2022 - Version - v1.0.2

## **Version**

- Module: Blaze\_PowerZone Connect 2 Zone Series With Dante
- Firmware: 1.2.0-beta.2
- MC4 FW: 2.6000.00026
- Crestron Home Version - v3.011.0070
- Simpl Windows - 4.18
- Device Database - 200.14000.001.00
- Crestron Database - 210.0500.001.00
- Simpl+ - 4.06
- Simpl+ Cross Compiler - 1.3
- Vision Tools Pro-e - 6.2.02
- Smart Graphics Version - 2.17.00.05

## **Enhancements**

- Internal fixes for release.

## **Bug Fixes**

- N/A

## **Exceptions**

- N/A

## **User Impacted**

- N/A

Date 11th March 2022 - Version - v1.0.1

## **Version**

- Module: Blaze\_PowerZone Connect 2 Zone Series With Dante
- Firmware: 1.2.0-beta.2
- MC4 FW: 2.6000.00026
- Crestron Home Version - v3.011.0070

- Simpl Windows - 4.18
- Device Database - 200.14000.001.00
- Crestron Database - 210.0500.001.00
- Simpl+ - 4.06
- Simpl+ Cross Compiler - 1.3
- Vision Tools Pro-e - 6.2.02
- Smart Graphics Version - 2.17.00.05

## **Enhancements**

- Crestron Home Initial Release

## **Bug Fixes**

- N/A

## **Exceptions**

- N/A

## **User Impacted**

- N/A

Date 7th March 2022 - Version - v1.0.0

## **Version**

- Module: Blaze\_PowerZone Connect 2 Zone Series With Dante
- Firmware: 1.2.0-beta.2
- Simpl Windows: 4.18
- MC4 FW: 2.6000.00026

## **Enhancements**

- Initial Release

## **Bug Fixes**

- N/A

## **Exceptions**

- N/A

**User Impacted**

- N/A